

Electric wine opener - battery operated

SKU: TP1P911.411
Categorie:

This battery operated electric corkscrew uncorks a bottle of wine with the push of a button. Including 4 AA batteries. Packed in a giftbox.



General information		
Product Life Cycle	Current	
Brand	XD Collection	
Color	black	
_Color_Hex	#3D332B	
Material	ABS	
Countries of Origin	CHN	
PMS main colour	Black	
Item Height CM	26,2	
Item Dimensions	26,2 x ø 5 cm	
Item Weight Net Gr	340	
Item Weight Gross Gr	451	
Outer Carton Length CM	54	
Outer Carton Width CM	30	
Outer Carton Height CM	20,7	
Outer Carton Dimensions	54 x 30 x 20,7 cm	
Outer Carton Weight Net KG	4,5	
Outer Carton Weight Gross KG	5,5	
Outer Carton Qty	10	
Max Print Width Default MM	25	
Max Print Height Default MM	50	
Max Colors Default	5	
Max Print Area Default	25 x 50 mm	
All Print Codes	Pad Print	
Print Code Default	Pad Print	
Print Technique Default	Pad print	
Print Position Default	item front down	
Custom Sleeve	true	
Gift Wrapping	true	
Item Box Length CM	10,4	
Item Box Width CM	9,2	
Item Box Height CM	28,9	
Item Box Dimensions	10,4 x 9,2 x 28,9 cm	
Item Diameter CM	5	
Batteries	true	
Battery Type	AA	
Battery Weight Gr	93	
No of batteries	4	
Variations		
Attribute	SKU	Stock
#3D332B 	TP1P911.411	2754